

FLEECE TOP PEEL AND STICK HIGH TEMPERATURE

Self-adhesive underlayment that can be exposed to temperatures as high as 125 ° C (257 ° F). Ideal as a membrane under slate tile roofs.

- Excellent resistance to high temperatures
- Excellent dimensional stability
- Anti-slip

PRODUCT PURPOSE

Application	Waterproofing	
Building Part	Roofing	
Types of Slope	Outside steep slope	
Types of covering	Slate tiles	Sheet metal
	Asphalt shingles	Concrete and clay tiles
Substrates	Plywood	OSB

PRODUCT CHARACTERISTICS

Technology	SBS modified bitumen
Surface	Non-woven polyester
Underface	Two parts silicone release film
Reinforcement	Glass mat
Installation Method	Self-adhesive
Service temperature	Up to 125 ° C (257 ° F)
Maximum exposure	180 days

PACKAGING




Code	Width		Length		Thickness		Selvage Width	Net Area		Brute Area		Quantity (per pallet)
	m	in	m	ft	mm	mils	mm	m²	ft²	m²	ft²	
00300 (no box)	1	39	20	65	1.7	67	75	18,50	199,13	20	215	30

PROPERTIES

Properties	STANDARDS	901-PS
Roll weight	-	33 kg (73 lb)
Tensile strength, MD/XD	ASTM D1970	16.8 / 8.3 kN/m (95.9 / 47.4 lbf/po)
Ultimate elongation, MD/XD	ASTM D1970	27 / 34 %
Tear Resistance, MD/XD	ASTM D1970	440 / 343 N (99 / 77 lbf)
Static puncture	ASTM D5602	> 430 N (> 96,7 N)
Adhesion to plywood, 24 ° C (75 ° F)	ASTM D1970	11.5 kgf / 30.5 cm (25.3 lbf/pi)
Low temperature flexibility	ASTM D1970	Pass at -29 ° C (-20 ° F)
Water vapour permeance	ASTM E96 (PROCEDURE B)	1.2 ng/Pa•s•m² (0.02 perm)
Tear resistance	ASTM D1970	400 / 353 N (90 / 79 lbf)
Nail sealability	ASTM D1970	Pass

(Valeurs nominales)

INSTALLATION

Storage	Rolls should be stored upright, tape side up. If the products are stored outdoors, cover them with an opaque protective cover after removing the delivery packaging. Can withstand freezing but must be reactivated to at least 10 ° C (50 ° F) before installation.		
Minimum Application Temperature	10 °C (50 °F)		
Required Products	Product No. 510 Patching Compound		
Complementary products	Product No. 297-X X-Treme Primer	TRC Topcoats	
Tools Required	 Smoothing roller	 Tape measure	
	 Knife		
Surface Preparation	The substrate must be clean, dry and free of dust, grease or other contaminants.		
Installation Prerequisite	The use of Product No. 297-X X-Treme Primer is not required on most surfaces when the membrane is covered within 24 hours of installation.		
Installation	<ol style="list-style-type: none"> 1. If conditions require, prepare the substrate with Product No. 297-X X-Treme Primer. 2. Position the membrane parallel to the roof edge. 3. Cut the membrane 901-PS to the desired length. 4. Remove the silicone film, and secure the top of the membrane using shingle nails. 5. Use Product No. 510 Patching Compound to seal the ends joints before applying the next membrane. <p>Note: The longitudinal overlap must be 75 mm (3 in) and 150 mm (6 in) for the transverse overlap. Make sure the nails are hidden by a membrane.</p> <p>Refer to the ROOF INSTALLATION SYSTEM for waterproofing membrane installation to roof details and upstands.</p>		
Recommendations/ Limitations	<p>It is not recommended to use a product containing bitumen directly on softwood boards or flexible polyvinyl chloride. 901-PS allows for tile stacking up to a maximum of 10 tiles over a roof pitch up to maximum 6:12 for lugged or flat tiles without any slippage. For roof pitches in excess of these limitations, use battens to stack the tiles, or contact Tucson Rubberized Coatings for alternate stacking methods.</p>		

For UL product evaluation, see UL Evaluation ER-21824-01

